



PARTS CATALOGUE/TECHNICAL GUIDE

Cal. 5T82A

[SPECIFICATIONS]

Item		Cal. No.	5T82A
Movement			  (x 1.0)
Movement size	Outside diameter		Ø 27.6 mm
	Casing diameter		Ø 27.0 mm
	Height		3.3 mm
Time indication (Movement intervals)			<p>Main time: Hour, minute and small second hands (1 second)</p> <ul style="list-style-type: none"> • WORLD TIME: City hand (24 cities), WORLD TIME hour hand, WORLD TIME minute hand • ALARM: ALARM hour hand ALARM minute hand
Driving system			Step motor 4 pcs.
Additional mechanism			<ul style="list-style-type: none"> • Electronic circuit reset switch • Train wheel setting device • Date calendar • Instant setting device for date calendar • Battery life indicator (The small second hand moves at two-second intervals.) • System reset <ul style="list-style-type: none"> • WORLD TIME 24 cities WORLD TIME hand position adjustment • ALARM function Single-time ALARM
Loss/gain			Monthly rate at normal temperature range: less than 15 seconds
Regulation system			Nil
Measuring gate by quartz tester			Use 10-second gate.
Battery	Battery No.		SR927W
	Voltage		1.55 V
	Battery life		Approx. 3 years
Jewels			Nil

SEIKO WATCH CORPORATION

REMARKS ON REPAIRING CAL. 5T82A

The basic movement structures of Cal. 5T82A is similar to the previous Cal. 7T Series watches, and the knowledge and technique you have gained in handling the previous Cal. 7T Series watches will come in handy when you repair Cal. 5T82A.


When repairing, however, you are requested to have the full knowledge of the features characteristic of these watches and strictly observe the repairing and checking instructions provided in this guide so that the watches will be repaired correctly.

I. FEATURES

As Cal. 5T82A has new movement structures, the operating procedures for ALARM setting, time setting, and ALARM hand position adjustment differ from those of the previous Cal. 7T Series watches.

As a result of this structure change, the battery life of Cal. 5T82A has increased to 3 years as compared with that of the previous Cal. 7T series watches.

Cal. 5T82A WORLD TIME



1. ALARM FUNCTION

- The ALARM sounds only once at a designated time within the coming 12 hours and it is automatically disengaged.
- Pushing the crown back into the normal position after setting the ALARM will prevent the set ALARM time from changing by an accidental pressing of the button.

2. WORLD TIME FUNCTION

- Apart from the main time, the time in the city selected by the city hand is displayed with the designated WORLD TIME hands.
- The time in 24 cities is displayed in the 24-hour indication.
- **Button operation (Crown position: Original position)**
 - WORLD TIME city selection (turn clockwise)
 - WORLD TIME city selection (turn counterclockwise)

3. SYSTEM RESET

When an abnormal display appears, reset the built-in integrated circuit. The watch will resume its normal operation.


- **Button operation (Crown position: Second click)**

Press and hold buttons A and B at the same time for longer than 2 seconds.

REMARKS ON REPAIRING CAL. 5T82A

II. NECESSARY PROCEDURE AFTER BATTERY CHANGE

After installing the battery, reset the built-in integrated circuit, and then **set the time and adjust the ALARM and WORLD TIME hand positions** following the procedure below.



*Note** Pressing Button A for longer than 2 seconds here will allow you to resume the procedure again as indicated by the arrow if necessary.


Disassembling procedures Figs. : ① → ⑤⑨

Reassembling procedures Figs. : ⑤⑨ → ①


* For the type of oil and quantity of lubrication, refer to the following TECHNICAL GUIDE section.

Remarks on removing the winding stem

To remove the winding stem when taking out the movement from the case or while disassembling the parts during repair work, be sure to pull out the crown to the first click, and then, remove the winding stem while pushing the setting lever.




Lubricating of some parts is shown in "II. REMARKS ON DISASSEMBLING AND REASSEMBLING."



Lubricating of some parts is shown in "II. REMARKS ON DISASSEMBLING AND REASSEMBLING."

PARTS CATALOGUE


Cal. 5T82A



Lubricating of some parts is shown in "II. REMARKS ON DISASSEMBLING AND REASSEMBLING."

PARTS CATALOGUE

Cal. 5T82A



Lubricating of some parts is shown in "II. REMARKS ON DISASSEMBLING AND REASSEMBLING."

Remarks

The correct parts for the followings are determined based on the design of cases. Check the case number, and refer to "Watch Parts Catalogue CD-ROM" to choose corresponding parts.

* Holding ring for dial (0866 651)


③ Date dial (0878 526)

④③ Winding stem (0351 583)


• Point of distinction









Refer to the illustrations below to see the difference between those two types of pins.







① Pin for date dial guard
0027 973







22 Pin for train wheel bridge
0027 974



No.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
59	Assembling the switching unit and wheels Set the main plate. ↓ Lubricate the lower pivots of the rotors. ↓ Lubricate the contact area between the small second wheel and main plate. ↓ Lubricate the point of engagement of the switch lever B. ↓ Lubricate the axis of the switch lever B.	<div data-bbox="403 191 929 263"> <p>Lubricate the contact area between the small second wheel and main plate: Moebius F or AO-2</p>  </div> <div data-bbox="1220 191 1870 263"> <p>Lubricate the lower pivots of the rotors: Moebius F or AO-2</p>  </div> <div data-bbox="616 367 1556 1109">  </div> <div data-bbox="403 1045 750 1093"> <p><59> Set the main plate.</p>  </div> <div data-bbox="616 1133 1030 1212"> <p>Lubricate the point of engagement of the switch lever B: S-6</p> </div> <div data-bbox="907 1220 1523 1284"> <p>Lubricate the axis of the switch lever B: Moebius V or AO-3</p> </div> <div data-bbox="1579 311 2128 1412"> <p><Amount of lubricant> Refer to the illustrations below to see the right amount of lubricant.</p>  <p>(a) Overlubricated× (b) Appropriately lubricated◎ (c) Underlubricated×</p> <p>Appropriate amount◎ (Stone)</p>  <p>Appropriate amount◎ (Convex part)</p>  <p>Appropriate amount◎ (S-6)</p>  </div>




NO.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
58	Set the switch lever B.	<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p><53, 52> Rotor stator for city setting</p>  <p>Discrimination number : 7 Set the rotor stator.</p>  <p>Discrimination number : 0</p> </div> <div style="width: 35%; text-align: center;">  </div> <div style="width: 30%;"> <p><57> Set the rotor stator for ALARM.</p>  </div> </div> <div style="margin-top: 10px;"> <p><50, 49> Set the coil block for city setting and the coil block (A). Coil resistance: 2.10 KΩ ~ 2.70 KΩ</p> </div> <div style="margin-top: 10px;"> <p><51> Set the train wheel setting lever.</p> </div> <div style="margin-top: 10px;"> <p>Lubricate the axis of the setting wheel: Moebius V or AO-3</p> </div> <div style="margin-top: 10px;"> <p><58> Set the switch lever B.</p>  </div> <div style="margin-top: 10px;"> <p><55, 54> Set the coil blocks for ALARM and WORLD TIME. Coil resistance: 1.80 KΩ ~ 2.40 KΩ</p> </div> <div style="margin-top: 10px;"> <p><56> Set the rotor stator for WORLD TIME.</p>  </div>
56	Set the rotor stator for WORLD TIME	
	Lubricate the axis of the setting wheel.	
57	Set the rotor stator for ALARM.	
55, 54	Set the coil blocks for ALARM and WORLD TIME.	
53, 52	Set the rotor stator for city setting, and rotor stator.	
51	Set the train wheel setting lever.	
50, 49	Set the coil block for city setting and the coil block (A).	


NO.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
48	Set the center wheel & pinion and lubricate its convex part and inner edge of the ring.	<div data-bbox="472 188 976 328"> <p><48> Set the center wheel & pinion and lubricate as illustrated below. (2 points) : Moebius AII or AO-3</p>  </div> <div data-bbox="1079 217 2179 296"> <p><40, 39, 38, 37> Set the rotor for city setting, WORLD TIME rotor, ALARM rotor and step rotor.</p> </div> <div data-bbox="501 655 837 823"> <p><45> Set the minute wheel for WORLD TIME 24-hour indication.</p> </div> <div data-bbox="501 855 613 999">  <p>White</p> </div> <div data-bbox="488 1070 853 1142"> <p><44> Set the setting wheel.</p> </div> <div data-bbox="931 1110 1491 1214"> <p><43> Set and lubricate the winding stem: Lubricate the entire profile of the winding stem with Moebius V or AO-3.</p>  </div> <div data-bbox="501 1262 869 1334"> <p><47> Set the clutch wheel.</p> </div> <div data-bbox="1715 831 2179 887"> <p><46> Set the minute wheel for ALARM.</p>  </div> <div data-bbox="1648 1015 2179 1254"> <p><42> Set the yoke. • Remember to install the winding stem before setting the yoke. Otherwise the spring of yoke will lift the clutch wheel upward. The reset spring of the yoke is easily deformable. Handle it with extra care as deformation of the spring can cause reset failure as well as mode change malfunction.</p> </div> <div data-bbox="1413 1270 1794 1350"> <p><41> Set the setting lever. • Crown at the normal position.</p> </div>
	↓	
47	Set the clutch wheel.	
	↓	
46	Set the minute wheel for ALARM.	
	↓	
45	Set the minute wheel for WORLD TIME 24-hour indication.	
	↓	
44	Set the setting wheel.	
	↓	
43	Set and lubricate the winding stem.	
	↓	
42	Set the yoke.	
	↓	
41	Set the setting lever.	
	↓	
40, 39	Set the rotor for city setting and the WORLD TIME rotor.	
38, 37	Set the ALARM rotor and step rotor.	

[illegible]

NO.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
35	Set the second intermediate wheel for city setting.	<div data-bbox="465 188 1061 236" data-label="Text">< 30 > Set the first intermediate wheel for city setting.</div> <div data-bbox="1245 212 1650 260" data-label="Text">< 23 > Set the small second wheel.</div> <div data-bbox="1637 288 2152 371" data-label="Text">< 27, 26 > Set the fifth wheel and pinion and third wheel and pinion.</div> <div data-bbox="1693 405 2152 453" data-label="Text">< 25 > Set the fourth wheel & pinion.</div> <div data-bbox="1776 501 2152 624" data-label="Text">< 31, 32 > Set the center minute wheel for WORLD TIME and center minute wheel for ALARM.</div> <div data-bbox="1895 660 2007 815" data-label="Image"> </div> <div data-bbox="1850 847 2085 895" data-label="Caption">Center minute wheel for WORLD TIME</div> <div data-bbox="1765 938 2152 1031" data-label="Text">< 29 > Set the intermediate wheel for ALARM.</div> <div data-bbox="1709 1058 2101 1106" data-label="Text">< 33 > Set the minute wheel.</div> <div data-bbox="1496 1129 2074 1177" data-label="Text">< 34 > Set the spacer for center wheel & pinion.</div> <div data-bbox="891 1206 1606 1350" data-label="Text"> <div data-bbox="909 1209 976 1233" data-label="Text">< 24 ></div> <div data-bbox="909 1238 1518 1318" data-label="Text">Set and lubricate the city setting wheel as illustrated above. Lubricate the point of contact of the spacer for center wheel & pinion: Moebius A or AO-3.</div> </div> <div data-bbox="465 256 831 368" data-label="Image"> <div data-bbox="573 312 685 336" data-label="Text">Dark green</div> </div> <div data-bbox="465 384 938 456" data-label="Text"> <div data-bbox="483 392 904 440" data-label="Text">< 35 > Set the second intermediate wheel for city setting.</div> </div> <div data-bbox="595 472 804 592" data-label="Image"> <div data-bbox="595 552 663 576" data-label="Text">White</div> </div> <div data-bbox="465 624 864 695" data-label="Text"> <div data-bbox="472 632 857 679" data-label="Text">< 28 > Set the intermediate wheel for WORLD TIME.</div> </div> <div data-bbox="607 711 781 791" data-label="Image"> <div data-bbox="607 743 674 767" data-label="Text">White</div> </div> <div data-bbox="465 815 875 911" data-label="Text"> <div data-bbox="472 823 869 903" data-label="Text">Lubricate the point of contact of the spacer for center wheel & pinion : Moebius A or AO-3</div> </div> <div data-bbox="479 943 804 1126" data-label="Image"> </div> <div data-bbox="714 1166 864 1382" data-label="Image"> </div> <div data-bbox="479 1254 804 1302" data-label="Text"> <div data-bbox="483 1254 799 1302" data-label="Text">< 27, 26 > Set the fifth wheel and pinion and third wheel and pinion.</div> </div> <div data-bbox="479 1318 804 1366" data-label="Text"> <div data-bbox="483 1318 799 1366" data-label="Text">< 25 > Set the fourth wheel & pinion.</div> </div> <div data-bbox="479 1382 804 1430" data-label="Text"> <div data-bbox="483 1382 799 1430" data-label="Text">< 31, 32 > Set the center minute wheel for WORLD TIME and center minute wheel for ALARM.</div> </div> <div data-bbox="479 1445 804 1493" data-label="Text"> <div data-bbox="483 1445 799 1493" data-label="Text">< 29 > Set the intermediate wheel for ALARM.</div> </div> <div data-bbox="479 1509 804 1557" data-label="Text"> <div data-bbox="483 1509 799 1557" data-label="Text">< 33 > Set the minute wheel.</div> </div> <div data-bbox="479 1573 804 1596" data-label="Text"> <div data-bbox="483 1573 799 1596" data-label="Text">< 34 > Set the spacer for center wheel & pinion.</div> </div>
	↓	
34	Set the spacer for center wheel & pinion.	
	↓	
33	Set the minute wheel.	
	↓	
32, 31	Set the center minute wheel for WORLD TIME and center minute wheel for ALARM.	
	↓	
	Lubricate the point of contact of the spacer for center wheel & pinion.	
	↓	
30	Set the first intermediate wheel for city setting.	
	↓	
29	Set the intermediate wheel for ALARM.	
	↓	
28	Set the intermediate wheel for WORLD TIME.	
	↓	
27, 26	Set the fifth wheel and pinion and third wheel and pinion.	
	↓	
25	Set the fourth wheel and pinion.	
	↓	
24	Set and lubricate the city setting wheel.	
	↓	
23	Set the small second wheel.	


No.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
22	Set the train wheel bridge. ↓	<p><22> Set the train wheel bridge.</p> <p><21> Set the pin for train wheel bridge. • Turn the pin 90-degree clockwise to fix it using a screwdriver. • Make sure that the pin is put in the correct direction. ※ Never turn the pin more than 90 degrees.</p> <p>Lubricate the upper pivots of the rotor for city setting, WORLD TIME rotor, and ALARM rotor and step rotor : Moebius F or AO-2 ※Lubricate the upper pivot of each rotor (at four points) illustrated below.</p> <p>Upper pivot of the rotor</p> <p>Minute wheel</p> <p>Other portions</p> <p><19> Set the buzzer lead terminal.</p> <p><20> Set the battery connection (-).</p> <p>Lubricate the upper pivots of the minute wheel, center minute wheel for ALARM, city setting wheel, minute wheel for WORLD TIME and small second wheel: Moebius F or AO-2.</p> <p>*1 : The upper pivot of the minute wheel for WORLD TIME should be additionally lubricated. 5 points to be lubricated as illustrated above.</p>
21	Set the pin for train wheel bridge. ↓	
20	Set the battery connection (-) ↓	
	Lubricate the upper pivots of the rotor for city setting, WORLD TIME rotor, and ALARM rotor and step rotor. ↓	
19	Set the buzzer lead terminal. ↓	
*1	Lubricate the upper pivots of the minute wheel, center minute wheel for ALARM, city setting wheel, center minute wheel for WORLD TIME and small second wheel.	

NO.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
	Assembling the circuit unit	
18	Set the circuit block.	<div><17> Set the friction spring for second counting.</div> <div><18> Set the circuit block. Make sure that the circuit block is securely engaged with the two guide pins of the train wheel bridge. Take care so as not to deform these parts while setting the circuit block.</div>  
	↓	
17	Set the friction spring for second counting.	
	↓	
16	Set the conducting plate.	
	↓	
15	Set the circuit block cover.	
	Securely engage the four hooks.	
	↓	
14	Tighten the circuit block cover screws. (3 positions)	<div><14> Tighten the circuit block cover screws (3 positions.)</div> <div><15> Set the circuit block cover. Securely engage the four hooks.</div> <div><16> Set the conducting plate.</div> <div>Remarks on installing the circuit block cover. (hooking portions) <ul style="list-style-type: none"> • Take care so as not to deform the rotor stator or coil block. • Make sure that the circuit block cover is correctly aligned with the two pins of the train wheel bridge. * Inaccurate alignment of the circuit block cover can cause malfunction of the yoke, resulting in defects of date correcting function. • The hook of the circuit block cover is easily disengaged. Make sure that it is securely engaged with the pins all the way in at the four locations. • Unhook the circuit block cover from a side angle using a pair of tweezers or a screwdriver while gently pressing it down. • The conductive spring of the circuit block cover is easily deformable. Handle it with care so as not to deform it. </div>
		

NO.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
12	Set the battery clamp.	 <p data-bbox="421 339 826 403">< 12 > Set the battery clamp.</p> <p data-bbox="472 1064 1373 1128">< 11 > Tighten the battery clamp screws. (3 positions)</p>
	↓	
11	Tighten the battery clamp screws. (3 positions)	
	↓	
	Measure the current consumption.	


[illegible]

No.	PROCESS	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
2	Set the date dial guard. ↓	<div data-bbox="427 309 1093 405"> <p><1> Set the date dial guard. (2 positions)</p> <ul style="list-style-type: none"> • Turn the pin 90-degree clockwise to fix it using a screwdriver. ※ Never turn the pin more than 90 degrees. </div> <div data-bbox="1352 236 2148 384"> <p>Lubricating points of the calendar wheels: contact points between</p> <ul style="list-style-type: none"> ① Date dial and date jumper: Moebius F or AO-2 ② Main plate and date jumper: Moebius F or AO-2 ③ Date dial guard and date jumper: Moebius F or AO-2 </div> <div data-bbox="1585 421 2063 767"> </div> <div data-bbox="622 475 1541 1273"> </div> <div data-bbox="427 1235 880 1299"> <p><2> Set the date dial guard.</p> </div>
	Set the jumper.	
	↓	
1	Set the pins for date dial guard. (2 positions)	
	Lubricate the points of contact between:	
	① Date dial and date jumper.	
	② Main plate and date jumper.	
	③ Date dial guard and date jumper.	



No.	PROCESS	SPECIFICATIONS (QUALITY SPECIFICATIONS, HANDLING METHODS ETC.)	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
	Assembling the case		
11	Set the battery.	Pay extra attention so as not to short-circuit the battery.	<p>< 11 > Set the battery.</p> <ul style="list-style-type: none"> • Install the battery in the direction shown by the arrow in the illustration below. Installing the battery from any other angle may result in bending or deforming the battery connection (-).  <p><u>Be careful so as not to deform the conducting spring while installing the battery or movement.</u></p>
	↓		
	AC	Connect the AC component to the circuit block cover until a short circuit occurs to reset the integrated circuit.	
	↓		
	Set the movement.	Do not press the date dial down when handling the movement.	
	↓	※Be careful so as not to deform the conducting spring of the movement.	
	Check that the date changes correctly.	Make sure that the date changes smoothly without dragging.	
	↓		
	Set the holding ring for dial.	When installing the holding ring for dial, be careful so as not to unhook it.	
	↓		
	Set the dial.		
	↓		
	Preparation for installing the hands	Follow the instructions below before installing the hands.	
		(It is necessary to adjust the backlash in a certain direction in order to ensure the proper hand positions before installing the hands.)	
		Activate the city hand in the hand adjustment mode.	
		(→Press and hold Button A for 3 seconds or longer with the crown at the second click position.)	
		(Adjust the backlash by turning the city hand, which is located at the center, clockwise.)	

System Reset

- Connect the AC component to the circuit block cover until a short circuit occurs to reset the integrated circuit.



No.	PROCESS	SPECIFICATIONS (QUALITY SPECIFICATIONS, HANDLING METHODS ETC.)	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
			<p style="text-align: center;"><5T82A WORLD TIME></p>
	(12 o'clock position)		
	Set the WORLD TIME hour hand.		
	Set the WORLD TIME minute hand.		
	↓		
	(9 o'clock position)		
	Set the small second hand.		
	Check the hand position and hand installation height.		
	↓		
	(6 o'clock position)		
	Set the ALARM hour hand.		
	Set the ALARM minute hand.		
	Check the hand position and hand installation height.		
	↓		
	(Center)		
	Set the hour hand.		
	Set the minute hand.		
	Check the hand position and hand installation height.		
	Set the city hand.		
	Check the hand position and hand installation height.		

No.	PROCESS	SPECIFICATIONS (QUALITY SPECIFICATIONS, HANDLING METHODS ETC.)	ILLUSTRATIONS AND SPECIAL INSTRUCTIONS ETC.
43	Remove the winding stem.	Pull out the crown temporarily to the first click position when removing the winding stem.	<p><43></p> <ul style="list-style-type: none"> • Be careful so as not to deform the winding stem conducting spring of the circuit block cover while removing or installing the winding stem. <p><43> Set the winding stem.</p> <ul style="list-style-type: none"> • For a watch with a screw lock type crown, apply silicone grease (100,000 to 500,000 c.s.) to the point of contact between the winding stem and gasket of the crown. <p>A sufficient amount of silicone should be applied so that the entire surface becomes wet. (See the illustration below.)</p> 
	↓		
	Set the movement with dial and hands into the case.	Remove dust and dirt on the movement with dial and hands and inside of the case before casing	
	↓		
43	Set the winding stem.		
	↓		
*1	Set the buttons. (2 pieces)	*1: Only some models require this process. Whether a watch requires this process or not depends on the design of its case.	<p><10> Set the anti magnetic shield plate B.</p> 
	↓		
10	Set the antimagnetic shield plate B.	Make sure that it is securely set in the correct direction.	
	↓		
	Close the case back.		
			<p>Close the case back.</p> <ul style="list-style-type: none"> • Make sure that the circuit block cover is securely hooked before closing the case back.

Functional Inspection

Operational Specifications (Reference)

	Rotation	Button to press										
Normal position	Free	Button A: adjusting the WORLD TIME hands in the clockwise direction (stopping the ALARM while it is ringing)										
		Button B: adjusting the WORLD TIME hands in the counterclockwise direction (stopping the ALARM while it is ringing)										
First click position	Clockwise: Date setting	Button A: activating the ALARM demonstration function										
		Button B: setting the ALARM time (setting the ALARM time to the current time can reset the ALARM) (keep pressing Button B will quickly advance the ALARM hands.)										
Second click position	Hand position adjustment (Main time setting)	Button B: setting the ALARM time (keep pressing it to quickly advance the ALARM hands)	→	Button A (2 seconds)	→	Button B: setting the city hand position (keep pressing it to quickly advance the city hand)	→	Button A (2 seconds)	→	Button B: setting the WORLD TIME hands (keep pressing it to quickly advance the WORLD TIME hands)	→	Button A (2 seconds)
	System reset	<div><div></div><div></div></div> Press and hold both Buttons A and B at the same time for longer than 2 seconds.										

[illegible]

IV. VALUE CHECKING

● Coil block resistance

Coil block (A) (4002 700)	2.10 K Ω ~ 2.70 K Ω
Coil block for city setting (4002 700)	2.10 K Ω ~ 2.70 K Ω
Coil block for ALARM (4002 711)	1.80 K Ω ~ 2.40 K Ω
Coil block for WORLD TIME (4002 711)	1.80 K Ω ~ 2.40 K Ω

● Upconverter coil resistance : 150 Ω ~ 180 Ω

● Current consumption

For the whole movement	Less than 1.10 μ A (with 1.55 V supplied from a battery)
For the circuit block alone	Less than 0.30 μ A (with 1.55 V supplied from a battery)

● How to measure the current consumption

1. To measure the current consumption for the circuit block alone or for the whole movement, connect the each tester of S-860 to the appropriate positive (+) or negative (-) input terminal of the circuit block.

* When measuring the current consumption using the SEIKO Multi-Tester S-860, select the measurement range as follows:

For the whole movement:

Use the range of 40 μ A of SUPPLY V (= 1.55 V) & GATE TIME (2 S)

For the circuit block alone:


Use the range of 4 μ A of SUPPLY V (= 1.55 V) & GATE TIME (2 S)

* When measuring the current consumption for the circuit block alone, be careful not to damage or deform the pattern of the circuit block.

2. Connect the AC component to the positive terminal for 2 seconds until a short circuit occurs to reset the integrated circuit.
3. After the integrated circuit is reset, wait approximately for 10 seconds until a stable measurement is obtained, and then read the measurement.

* When measuring the current consumption for the circuit block alone, be sure to protect the integrated circuit from light.

* Refer to the illustration below to measure the current consumption for the circuit block alone.



V. TROUBLESHOOTING

	Symptom	Possible causes	Solutions
Movement	The watch stops operating.	The battery has been depleted.	Measure the battery voltage. Replace the battery with a new one.
		The hour wheel and the pinion of the minute wheel are not properly engaged. (Or the teeth of the hour wheel and/or minute wheel have been broken.)	Check the relevant parts, and replace the damaged parts with new ones.
		The hooking portions of the circuit block cover are not properly engaged, resulting in poor conductivity.	Securely attach the hooks of the circuit block cover to the main plate.
		The coil is broken.	Measure the coil block resistance. Replace the coil with a new one.
		One or more wheels have been contaminated with dirt, dust or other particles. An excessive amount of oil in the movement has caused adhesive forces among the parts. (wringing)	Remove dirt or dust and clean the contaminated wheels. Be careful so as not to damage the teeth of the plastic parts while cleaning.
	The current consumption for the whole movement exceeds the standard value.	Dirt, dust or foreign particles are adhered to the movement.	Remove dirt, dust or foreign particles and clean the movement.
		The driving pulse is generated in order to compensate the excessive load applied to the wheels. (The oil has deteriorated, leaked or run out.)	If the current consumption for the circuit block alone is within the standard value range, overhaul and clean the movement parts, and then make the measurement again.
	The current consumption for the circuit block alone exceeds the standard value.	The light from outside the movement is affecting the measurement.	Shut out the light, and make the measurement again.
		There is a defect in the IC (integrated circuit).	Replace the circuit block with a new one.
	The date dial shows an abnormal movement.	The date dial has become improperly engaged with the date driving wheel or disengaged from the date driving wheel.	Check the rotation and engagement of the date dial. Bend the date dial downward to adjust the clearance. Or replace the date dial with a new one.
	The date dial does not move.		
	The date does not change.		

TECHNICAL GUIDE

Cal. 5T82A

	Symptom	Possible causes	Solutions
ALARM/ WORLD TIME	One or more ALARM hands, WORLD TIME hands or city hand have stopped moving or show an abnormal movement.	The relevant coil is broken.	Measure the coil block resistance. Replace the coil with a new one if necessary.
		An excessive load is being applied to the ALARM and/or WORLD TIME wheels due to dust or foreign particles adhering to them or oil starvation.	Clean the relevant parts and lubricate with an adequate amount of oil.
	The step motor shows an abnormal movement.	There is a crack on the circuit block switch pattern.	Replace the circuit block with a new one.
		The step motor has been deformed.	Replace the stator with a new one.
	The buttons do not operate normally.	The amount of oil around the buttons is insufficient.	Clean the buttons and lubricate appropriately.
		The circuit block pattern has been broken or bent.	Adjust the circuit block pattern or replace the circuit block with a new one.
	The ALARM does not sound.	The upconverter coil is broken.	Replace the circuit block with a new one.
		The piezoelectric element is broken or out of alignment.	Remount the piezoelectric element or replace it with a new one.
Exterior parts	The ALARM sound is too small.		
	The crown falls off.	The winding stem is not securely installed. (The setting lever and yoke are disengaged.)	Check the main plate, winding stem, setting lever and yoke. Replace the defective parts with new ones.
	The current consumption exceeds the standard value.	An excessive load is being applied due to friction among the hour, minute and ALARM and/or WORLD TIME hands.	Adjust or remount the relevant hands.
	Small amount of water/blur inside of the glass persists.	Water resistance is deteriorated. The watch has been subjected to water pressure that exceeds the guaranteed degree.	Investigate the causes to take necessary measures, while cleaning inside of the watch.